

Group Policy Management

Target

 Configures password policies, shared printers, shared folders, etc. With the help of Group Policy Manager. Test all made group policies on the workstation.

Tasks


- 1. If necessary, start the VirtualBox virtualization software.
- 2. If necessary, start the Apollo (Windows 2016) virtual machine.
- 3. Log in with your Administrator username and password to the Passw0rd§ server.

Default Domain Policy

- 4. At the top right of the Server Manager window, click Tools > Group Policy Management.
- 5. In the Group Policy Management console, expand from the tree Forest: cyberse.local > Domains > cyberse.local.
- 6. Right-click Default Domain Policy and select Edit.
 - N.B! This is the only Policy (Group Policy) where password policies can be configured.
- 7. Expand Computer Configuration > Policies > Windows Settings > Security Settings > Account Policies, and then click Password Policy.
- 8. Change the value of Enforce password history to 6, Maximum password age to 52, and Minimum password length to 8.
 - In thecase of Minimum password length, it would be a good idea to set the value to, say, 16.
 - Consider what the settings you set above do
- 9. Select Account Lockout Policy and change the Account lockout threshold to 3, click OK, and accept the proposed values.
 - Consider what the settings you set above do

Audit of the login


- Expand Computer Configuration > Policies >
 Windows Settings > Security Settings > Local
 Policies, and then click Audit Policy.
- 11. Double-click audit account logon events.
- 12. Valise Define these policy setting, Success and Failure checkboxes.



13. Close the Group Policy Management editor window.



- 14. Make sure Default Domain Policy is selected and select the Settings tab in the adjacent properties window.
- 15. View the configurations made in the properties window.
 - Tap on Show all to make all the specified policies appear.





Make the following Group Policies for Pasila OU (all domain users)

- 16. Configuring Printer 1 (HP LaserJet 4250 PCL 5)
 - Expand from the tree cyberse.local > Pasila.
 - Right-click on it and select Create and Link a GPO Here from the menu that opens, as well as enter "Group Policy Pasila printer" as the group policy name.
 - Configure the printer in the Print Management console:
 - In the Server Manager window, click Tools > Print Management to start Print Management.
 - In the Print Management window, expand Print Servers Apollo(local) and select Printers.
 - Right-click on the HP LaserJet 4250 PCL Class Driver printer and select Deploy with Group Policy from the menu that opens.
 - o Click Browse...
 - o In the menu that opens, search for the Group Policy Pasila printer and click OK.
 - Under Deploy this printer connection to the following: select the The users that this GPO applies to (per user) check box.
 - o Click Add.
 - Click OK a couple of times.
 - Close the Print Management window.
- 17. The ID of the last user logged on to the workstation is not displayed when the next user logs on
 - Expand from the tree cyberse.local > Pasila.
 - Right-click on it and in the menu that opens, select Create and Link a GPO Here, as well as enter "Hide Username" as the name of the group policy.
 - Right-click and select Edit.
 - Select Computer Configuration > Policies > Windows Settings > Security Settings -Local Policies > Security Options.
 - Double-click the Interactive logo: Do not display last user name.
 - Select the Define this policy setting: check box, select the Enable option box, and then click OK.
 - Close the Group Policy Management Editor window.
 - In the Active Directory Users and Computers console, move the Win10 workstation from the Computers store to Pasila OU

BE SURE TO TEST THE OPERATION OF GROUP DEPLOYMENTS ON THE WORKSTATION FROM TIMETO TIME! Update Group Policy at the command prompt by using **gpupdate /force**



Follow the following Group Policy for Management OU:

- 18. Connecting and attaching a network drive Economy to the letter "T"
 - Expand from tree cyberse.local > Pasila > Management
 - Right-click on it and in the menu that opens, select Create and Link a GPO Here, as well as enter the group policy name "Economy folder mapping".
 - Right-click and select Edit
 - Select User Configuration Preferences Windows Settings
 - Right-click on Drive Maps and select New Mapped Drive
 - In the Location: box, type \\Apollo\Economy
 - Select the Reconnect: box, and in the Label as: box, type Economy
 - Under Drive Letter, select the letter T
 - Click OK. Close the Group Policy Management Editor.

Do the following Group Policies for Cyber OU:

- 19. Connecting and attaching a network drive Economy to the letter "T".
 - Expand from tree cyberse.local > Pasila > Cyber
 - Right-click on it and in the menu that opens, select Link an Existing GPO and select
 "Economy folder mapping" Group Policy and click OK.
- 20. Configuring Printer **2** (Canon LBP5360) to Cyber OU(configure via Group Policy Management as follows)
 - Expand from tree cyberse.local > Pasila > Cyber
 - Right-click on it and in the menu that opens, select Create and Link a GPO Here, as well as enter "Cloud Printer" as the group policy name.
 - Right-click and select Edit.
 - Select User Configuration > Policies > Windows Settings.
 - Right-click on Deploy Printer.
 - In the Enter printer name: box, type \\Apollo\Canon LBP5360 and click Add and OK, and then close Group Policy Management Editor.




For Cloud OU, do the following Group Policy:

- 21. To prevent access to C drive:
 - Expand from tree cyberse.local > Pasila > Cloud
 - Right-click on it and in the menu that opens, select Create and Link a GPO Here, as well as enter "C drive blocker" as the name of the group policy.
 - Right-click and select Edit.
 - User Configuration > Policies > Administrative Templates > Windows Components
 > File Explorer.

Choose one of the following options:

- ✓ Hide these specified drives in My Computer or
- ✓ Prevent access to drives from My Computer



BE SURE TO TEST THE OPERATION OF GROUP DEPLOYMENTS ON THE WORKSTATION! Update Group Policy at the command prompt by using **gpupdate /force**

